

GTH B.V. Dr. Frederiksstraat 39 7582 AX Losser The Netherlands

+31 (0)53 538 37 55 +31 (0)6 30 15 47 08 info@qthbv.nl www.gthkoelkleding.nl





Activated within 10 sec.

Datasheet

Powercool SX3 Arm cooler

PROPERTIES

- No more cooling elements needed, only 0.7 liters of water
- · Activated within 5 seconds
- Cooling down to 12 degrees Celsius Offers up to 20 hours
- of pleasant cooling
- High wearing comfort
- · Machine washable and antibacterial

SPECIFICATIONS

Item Col

Size Mod

Coc

Mat

n code:	27105101
ors:	Black
es:	One size
del:	Arm cooler
oling Energy:	2600 Kj/L
erial:	100% Polyester (outside)
	100% COOLINE® (inside)
	DEOXX Fresh system





The fastest and most ecological cooling system ever!

The third generation COOLINE high-tech fleece is further developed and is therefore 100% lighter, faster cooling and more effective.

NATURAL COOLING

E.COOLINE® mimics the cooling system of the body in which the heart pumps the blood and transports heat through the skin. A sweat develops on the skin, which has a cooling effect on the body due to the evaporation. Unfortunately, this cooling system is limited. Unlike the human body, E.COOLINE®'s high-tech fleece can absorb and retain its weight in water several times. The water is only released by evaporation and not by (mechanical) pressure. In short, the body is still cooled by evaporation.

How do I activate my Powercool SX3 cooling products?



Immerse the product in cold water until it is saturated and does not absorb any more water. This will only take a few seconds



STEP 2

Apply pressure to the product firmly until no more water comes out and if necessary, wipe it off with a towel. Please note: do not wring out the product!



The Powercool SX3 product is now activated, ready to use and will provide up to 20 hours of pleasant cooling.

IMPORTANT



WASHING INSTRUCTIONS

Wash separately. The product can be dry-cleaned, washed by hand or by gentle / delicate wash (do not tumble dry) at up to 30°C. Use the special liquid laundry "DEOXX ecowash" or other pH-neutral detergent (such as TOKO®ecowash) and rinse well with clear water. Do not use fabric softener, do not tumble or dry the product in a spin dryer, do not wring. To completely dry the material, hang it to dry for 1-3 days.

IMPORTANT NOTICE

Please observe the maximum weight capacity for your washing machine: the high-tech fabric can absorb 2-3 litres (kg/m2) of water. Do not store the wateractivated product in a closed bag or packaging. Only wash with closed Velcro and/or zip fasteners!